



LOWREY
Virtual Orchestra
Specifications *EY300*
Fanfare

Performer Play **Music Styles** as **Full Band**- a complete band or orchestra, **Pianist**-beautiful piano oriented styles, **Guitarist**-a variety of guitar based styles.
Group 2 expands **Music Style** selection to 72 dynamic styles.

	Full Band	Pianist	Guitarist
Music Styles	Standards	Frank & The Count Smooth Fox Trot	2-Beat Piano Jazz Club Guitar Swing Gypsy Rag
	Country	Roadside Café Country Swing	Rinkie Tink Floyde Piano Country Basic On The Trail
	Broadway	Opener New York Swing	Awesome Piano Soliloquy The Train E. Coast Swing/Jive
	Smooth	EZ 4/4 (8-Beat) Jazzee	Heart Songs Piano Offering Guitar 4/4 Soft Country
	Rock	8-Beat Rock Fab 4	Memphis Piano Rock & Roll Piano 50's Rock Guitar Ringo's Sub
	3/4	EZ Waltz Modern Jazz Waltz	Southern 3/4 Piano 3/4 Guitars 3/4 Cowboy Waltz
	Traditional	March / Polka Swing March (6/8)	Classical Piano Arpeggio Piano Jazz Piano My Gal
	Gospel	Hand Clappin' Southern	Gospel Ballad Soulful Guitars Chicago Blues
	Latin	Ballroom Latin Bossa Nova	Piano Bossa Tango Latin Guitar Trios Romanticos
	Ballad	Wonder Full World Spots of Ink	50's Love Ballad Piano Colour 6/8 Guitar Denver Pickin
	Pop	Pop Shuffle Bandstand	Ragtime Piano Boogie Piano Guitar Standard Electric Standard
	Mix	Aloha Disco	Candelabra Smokey Lounge Basic Shuffle Supreme Shuffle
	Style Features	Lock Accomp., Orch Plus, Intro Ending, Start Stop, Fill, Drum Volume, Tempo Control, Tempo Lock, Beat Indicator, Tap Tempo	
Golden Harp	Add a graceful arpeggio to your music. Four dynamic patterns: Up/Down, Up Only, Down Only, Virtuoso.		
Easy Play	Easy Button, MCS-One Finger Chords, MCS Chord Lights, Chord Memory, Auto Bass 1, Auto Bass 2, Pedal Magic, One Finger Harmony, Lighted Keyboard ABC's, Fake It!		
Harmony	One-Finger Harmony - AOC, Duet, Open, Octave Duet, Rock, Octave, Country, Block, Harmony Lock.		
Style Setup	Nine complete sound settings designed for each Music Style.		
Setups	Nine complete upper & lower keyboard sound settings.		
Category Setups	Nine complete upper & lower keyboard sound settings for each musical category: Symphonic, Jazz/Swing, Country, Modern.		
Bank Setups	Nine complete upper & lower keyboard sound settings, Customize and Save using Memorize		
Song Setups	206 complete sound settings inspired by certain song titles.		
Songs	60 Song Performances. One Fanfare Demo Song + 59 Lowrey Magic Class Songs.		
Bank Storage	Save your customized Bank Setups so you will always have them. Store/Save up to 20 groups of nine complete setups.		

Upper Sounds

Flutes (organs)	Sweet	Solo 8'	Jazz 3	8' + 4'
	Rich	Solo 4'	Open	8' + 2'
	Mellow	Jazz 1	Full	8' + 4' + 2'
	Solo 16'	Jazz 2	Pipe	
Vibra Trem	Fast or Slow settings-adds motion and authenticity to organ sounds.			
Sustain	Add the Sustain effect to upper Flutes sounds.			
Ensemble (organs)	Strings 8	Strings 16+8	Strings 8+Vocal Ens 8	Strings 16+Vocal Ens8
	Strings 16	Vocal Ensemble 8	Strings 16+8+Vocal Ensemble 8	
Sustain	Add the Sustain effect to (upper) Ensemble sounds.			
Orchestral Sounds				
Pianos	Piano: 9ft. Grand	Piano: HonkyTonk	Piano-El: Dolce	Piano: Octaves
	Piano: Concert Gr	Piano-El: Detune 1	Piano-El: Wurlly	Piano: Society
	Piano: LX	Piano-El: Classic	Piano: Toy	Harpsichord Plec.
Guitars	Guitar: Acoustic	Guitar: Jazz 1	Guitar: Hawaiian	Guitar: Elec. Blues
	Guitar: Country	Guitar: Nylon	Guitar: Steel	Guitar: Elec. Strat
	Guitar: Dobro	Guitar: Flamenco	Guitar: Tremolo	Guitar: Rock
Strings	Strings: Ensemble 1	Strings: Finale	Violin: Smooth	Fiddle
	Strings: Ensemble 2	Strings: Octave	Viola	Fiddle: Slide
	Strings: Ensemble 3	Pizzicato	Cello	Harp
Wood Winds	Sax: Tenor Breathly	Flute: Flutter	Bassoon	Sax: Alto Mellow
	Clarinet	Organ: Theatre Big	Sax: New Years	Sax: Baritone
	Flute: Jazz	Oboe	Sax: Alto	Sax: Tenor-Growl
Brass	Trumpet: Lead	Trumpet: Muted	Trombone: Tommy	Organ: Mixture
	Trumpet: Louis	Trumpet: Plunger	Trombone: Slide NT	French Horn
	Trumpet: Shake	Trumpet: Wah-Wah	Trombone: Dixie	Flugel Horn
Mallets	Vibes	Marimba: Soft	Bells: Crystal	Agogo Bells
	Vibraphone	Bells	Bells: Hand	Woodblock
	Marimba	Bells: Church	Steel Drums	Xylophone
Vocals	Choir: Aah (Near)	Xtra: Choir-Itopia	Scat: DooBah (Dao)	Vocal: La
	Choir: Aah (Far)	Scat	Scat: Swingle	Vocal: Bah
	Choir: Stage Ooh	Scat: DooBah	Vocal: Ooo (Wah)	Vocal: Doo

Orchestral Sounds-More

More (upper)	Accordion	Guitar: Flamenco 2	Organ: 8' Celeste	Organ-Combo: 60's
	Accordion: Lyric	Guitar: Hawaiian 2	Organ: Airy Pipes	Organ-Combo: "B"
	Accordion: Musette	Guitar: Jazz 2	Organ: Baroque	Pan Flute
	Animal: Cat	Guitar: Mute-Dynam	Organ: Church Det.	Piano-El: Crystal
	Animal: Dog	Guitar: Spanish	Organ: Church Oct.	Piano-El: Detune 2
	Bag Pipe	Harmonica	Organ: Kinura	Piccolo
	Banjo	Harmonica: Amp'd	Organ: Med. Ens.	SFX: Pop
	Blown Bottle (Jug)	Harmonica: Pocket	Organ: Mellow Ens.	Recorder
	Calliope	Hit: Orchestra	Organ: Post Horn	Strings: Chamber
	Clavinette	Kazoo	Organ: Principal	Test-Sound
Ens: Big Band	Mandolin	Organ: Reed Pipes	Theremin	
Vocal: La	Mandolin: Orch.	Organ: Stg.Celeste	Vocal: Fah	
Guitar: 12-String	Ocarina	Organ: Stopped	Whistle	
Guitar: Elec. Brite	Organ Perc: 2-2/3'	Organ: Theatre Vox	Xtra: Atmosphere	
Guitar: Elec. Detune	Organ Perc: 4'	Organ: Tibia Soft	Xtra: Soft-New Age	
Orchestral On/Off	Control from which keyboard Orchestral, Solo, and Organ sounds are played.			
Orch. Effect	Activate certain effects for Orchestral Sounds with the touch of a button.			
Lower Right	Place upper sounds from Orchestral, Organs, and Solo for play on the lower keyboard.			
Octave Down	Move the pitch of Orchestral and Solo sounds, played on the lower keyboard, down one octave.			
Solo Sounds				
Solo	Accordion	Organ: Theatre Big	Piano: 9ft. Grand	Trombone: Slide- NT
	Animal: Cat	Vocal: Lah	Piano: Concert Gr.	Trombone: Tommy
	Animal: Dog	French Horn	Piano: Octaves	Trumpet: Lead
	Bag Pipe	Guitar: Country	Piano: Society	Trumpet: Louis
	Banjo	Guitar: Elec. Blues	Piccolo	Trumpet: Muted
	Bassoon	Guitar: Elec. Strat	SFX: Pop	Trumpet: Plunger
	Bells	Guitar: Jazz 1	Recorder	Trumpet: Shake
	Bells: Church	Guitar: Elec. Rock	Sax: Alto	Viola
	Bells: Crystal	Guitar: Tremolo	Sax: Baritone	Violin: Smooth
	Blown Bottle (Jug)	Harmonica: Amp'd	Sax: Tenor-Breathy	Vocal: Bah
	Cello	Harmonica: Pocket	Sax: Tenor-Growl	Vocal: Doo
	Clarinet	Kazoo	Scat	Whistle
	Fiddle	Mandolin	Scat: DooBah (Dao)	Xylophone
	Fiddle: Slide	Oboe	Strings Octave	Xtra: Solo-Best 1
	Flugel Horn	Ocarina	Test-Sound	Xtra: Solo-Saw 1
Flute: Jazz	Pan Flute	Theremin	Xtra: Solo-Square	
Slide	Add the Portamento effect to Solo sounds.			

Lower Left Sounds

Flutes	Organ 8	Organ 4	Organ 8 + 4	
Ensemble	Strings	Vocals	Vocals + Strings	
More	Accordion	Guitar: Elec. Detune	Organ: Principal	Strings: Pizzicato
	Bass: Acoustic	Guitar: Elec. Strat	Organ: Stopped	Recorder
	Bass: Elec. Deep	Guitar: Jazz 1	Organ: Tibia Soft	Sax: New Years
	Bass: Finger Slap	Guitar: Jazz 2	Organ-Combo: 60's	Scat
	Bass: Fretless	Guitar: Mute-Dynam	Organ-Combo: "B" 2	Steel Drums
	Bells	Guitar: Nylon	Organ: 8' Celeste	Strings: Ensemble 1
	Blown Bottle (Jug)	Guitar: Elec. Rock	Piano: 9ft. Grand	Strings: Ensemble 2
	Brass Section 2	Guitar: Steel	Piano: Concert Gr.	Strings: Finale
	Calliope	Guitar: Tremolo	Piano: LX	Strings: Octave
	Choir: Aah (Far)	Harp	Piano: El. Detune 2	Vibes
	Choir: Ooh	Harpsichord	Piano: HonkyTonk	Vocal: Doo
	Ens: Big Band	Mandolin: Orch	Piano: Society	Vocal: Ooo (Wah)
Flugel Horn	Marimba: Soft	Piano-El: Classic	Xtra: Soft-New Age	
Guitar: Acoustic	Organ: Baroque	Piano: El. Detune 1	Xtra: Soft-Sine	
Guitar: Elec. Blues	Organ: Med. Ens.	Piano-El: Dolce	Xtra: Soft-Sweep	
Guitar: Elec. Brite	Organ: Mellow Ens.	Piano-El: Wurlly	Xtra: Soft-Warm	

Bass / Pedals Sounds

Organ	Organ 16 + 8	Organ 16	Organ 8
More	Assign any of the 64 Lower Left - More sounds to Bass Pedal - More.		
Graphic Mixer	Mix your sound with Master, Reverb, Bass, Style, Lower controls.		
Balance	Control the balance between the melody and accompaniment sounds.		
Transpose	Easily change the key in which you play, up or down, over the whole 12 key range.		
Connections	1/4 Stereo Headphone Jack for private play, Stereo Input for portable music players-like ipod, Microphone in-with volume control, Line In/Out- In for other audio devices, Out for connection to external sound system.		
Foot Switches	Glide/Sustain, Fill. <i>Control Fill, Start Stop, Vibra Trem, or No Chord with Right Foot Switch.</i>		
Display	Scroll, Feature, Select Function; Contrast Setting; Tempo, Chord, Key Display; Songs Menu, Song Setup Menu, Sounds Menu, Features Menu.		
Music Recorder	Record & Play Back Fanfare performance. Store approximately 20 performances.		
Features	Levels	Sustain Lengths	Orch. Solo
	AOC	Edit Sounds	Orch. Effects
	Repeat/Slide	Drums & Keyed Bass	Right Foot Switch
	Chain Songs	Light Show	Rename Bank Setup
Keyboard Touch	Instantly select between two keyboard velocity settings: Off=Constant Velocity <i>even touch sensitivity.</i> ON=Dynamic Velocity <i>piano-like touch sensitivity.</i>		
	44 Notes Upper, 61 Notes Lower, Lower Keyboard Split (moveable)		
Pedals	13 Notes		
Cabinet	Natural Cherry/Mohagony Finish, Integrated Music Rack folds down to cover the button panel.		
Bench	Padded Seat, Opens for Music Storage.		
Bench Pack	Lowrey Songbook with 50 Easy Play Notation Songs, Owner's Guide.		
Dimensions	(Uncrated) 45.00" Wide x 24.50" Deep x 40.75" High-Music Rack down, 46.00" High-Music Rack up. Weight: 189.00 lbs (with bench).		