


<b>Performer</b>	Play <b>Music Styles</b> as <b>Full Band</b> - a complete band or orchestra, <b>Pianist</b> -beautiful piano oriented styles, <b>Guitarist</b> -a variety of guitar based styles.			
	<b>Full Band</b>	<b>Pianist</b>	<b>Guitarist</b>	
<b>Music Styles</b>	<b>Standards</b>	Frank & The Count	2-Beat Piano	Guitar Swing
	<b>Country</b>	Roadside Café	Rinkie Tink	Country Basic
	<b>Smooth</b>	EZ 4/4 (8-Beat)	Heart Songs	Guitar 4/4
	<b>Rock</b>	8-Beat Rock	Memphis Piano	50's Rock Guitar
	<b>Traditional</b>	March / Polka	Classical Piano	Jazz Guitar
	<b>Gospel</b>	Hand Clappin'	Gospel Ballad	Guitars
	<b>Latin</b>	Ballroom Latin	Piano Bossa	Latin Guitar
	<b>3/4</b>	EZ Waltz	Southern 3/4	Guitars 3/4
<b>Style Features</b>	Intro Ending, Start Stop, Fill, Tempo Control, Drum Volume, Beat Indicator.			
<b>Easy Play</b>	Easy Button, MCS-One Finger Chords, MCS Lights, Chord Memory, Automatic Bass, One Finger Harmony, Keyboard ABC's, Fake It!			
<b>Harmony</b>	One-Finger Harmony - AOC, Duet, Rock, Octave.			
<b>Style Setup</b>	A complete sound setting for each Music Style.			
<b>Song Setups</b>	100 complete sound settings inspired by certain song titles.			
<b>Songs</b>	30 song performances from Lowrey Magic class plus EZ4 Demonstration songs.			
<b>Upper Sounds</b>				
<b>Organs</b>	Sweet	Full	Pipe	Strings 8
	Rich	Jazz	Solo	Strings 16
<b>Vibra Trem</b>	Fast or Slow settings-adds motion and authenticity to organ sounds.			
<b>Orchestral Sounds</b>				
<b>Pianos</b>	Piano: Grand	Piano-El: Detune 1	Piano: Society	
	Piano: Honky-Tonk	Piano-El: Classic	Harpsichord	
<b>Guitars</b>	Guitar: Acoustic	Guitar: Jazz	Guitar: Hawaiian	
	Guitar: Country	Guitar: Nylon	Guitar: Rock	
<b>Strings</b>	Strings: Ensemble 1	Strings: Pizzicato	Viola	
	Strings: Ensemble 2	Violin	Cello	
<b>Wood Winds</b>	Sax: Breathly Tenor	Flute	Sax: Alto	
	Clarinet	Oboe	Sax: Baritone	
<b>More</b>	Accordion	French Horn	Organ: Perc. 2 2/3	Trombone: Tommy
	Animal: Cat	Flugel Horn	Organ: Tibia Soft	Trumpet
	Animal: Dog	Guitar: Mute-Dynamic	Organ-Combo: Rock	Trumpet: Muted
	Bag Pipe	Harmonica: Pocket	Organ-Combo: 60's	Vibes
	Banjo	Harp	Pan Flute	Vocal: Doo
	Bells: Crystal	Mandolin	Piano-El: Detune 2	Whistle
	Bells: Church	Marimba	Piano: Toy	Xylophone
	Brass Section	Organ: 8' Celeste	Sax Section	Xtra: Solo-Saw
	Choir	Organ: Church	Scat	
Ensemble: Big Band	Organ: Perc. 4	Steel Drums		



### Lower Sounds

<b>Lower Ensemble</b>	Strings	Organ 8	Organ 8 + 4	
	Vocals	Organ 4	Organ8+Strings	
<b>More</b>	Bass: Acoustic	Guitar: Jazz 2	Piano: Grand	Strings: Ens. 1
	Bass: Electric	Guitar: Nylon	Piano-El: Detune 1	Strings: Ens. 2
	Bass: Finger Slap	Marimba	Piano: El. Detune 2	Vibes
	Choir	Organ: 8' Celeste	Piano: El. Dolce	Vocal: Doo
	Guitar: Acoustic	Organ: Rock	Scat	Xtra: Soft-Warm
<b>Volume Control</b>	Master, Bass, Accompaniment, Expression Pedal.			
<b>Headphones</b>	1/4 Stereo Headphone Jack.			
<b>Foot Switches</b>	Glide/Sustain, Fill.			
<b>Display</b>	Scroll, Feature, Select Function; Contrast Setting; Tempo, Chord, Key Display; Songs Menu, Sounds Menu, Song Setup Menu.			
<b>Features</b>	Lower Split, Touch (Key Velocity), Drums Only, Keyed Bass, Orch Octave, Orchestral Volume Level, Transpose.			
<b>Keyboards</b>	44 Notes Upper, 61 Notes Lower			
<b>Keyboard Features</b>	Lower Keyboard Split (moveable), Orchestral to Right Split, Orchestral On/Off.			
<b>Cabinet</b>	Simulated Rosewood, Matching Music Rack.			
<b>Bench</b>	Padded Seat.			
<b>Bench Pack</b>	Lowrey Songbook with 50 Easy Play Notation Songs, Owner's Guide.			
<b>Dimensions</b>	(Uncrated) 42.5" Wide x 20.25" Deep x 35.25" High-Music Rack removed, 42.5" High-Rack Installed. Weight: 106.00 lbs (with bench).			