







Performer Play Music Styles as Full Band- a complete band or orchestra, Pianist-beautiful piano oriented styles, Guitarist-a variety of guitar based styles.

Music Styles	Full Band		Pianist	Guitarist	
Standards	Frank & The Count	March / Polka	2-Beat Piano	Guitar Swing	
Country	Roadside Café	EZ Country	Rinkie Tink	The Train	
Smooth	EZ 4/4	Cab Drivin'	Heart Songs	Jazz Guitar	
Latin	Ballroom Latin	Trios Romanticos	Piano Bossa	Latin Guitar	
Rock	8-Beat Rock	Bandstand	50's Love Songs	50's Rock Guitar	
3/4	EZ Waltz	Swing March	Southern 3/4	Guitars 3/4	
Style Features	Intro Ending, Start Stop, Fill, Tempo Control, Beat Indicator.				
	A complete sound setting designed for each Music Style.				
Easy Play	Easy Button, MCS-One Finger Chords, MCS Lights, Chord Memory, Automatic Bass, One Finger Harmony, Keyboard ABC's, Home.				
Songs	30 selected song performances from Lowrey Magic class books; Red Books 1, 2, and 3.				
Song Setup	100 complete sound setups, including a Music Style, for a specific song title and songs similar to that song title.				

	Upper Sounds					
	Orchestral					
Pianos	Piano: Grand	Piano: Octaves	Piano-El: Classic	Piano: Toy		
	Piano: HonkyTonk	Piano: Society	Piano-El: Wurly	Harpsichord		
Guitars	Guitar: Acoustic	Guitar: Jazz 1	Guitar: El. Clean	Guitar: Muted		
	Guitar: Nylon	Guitar: Country	Guitar: Rock	Guitar: Hawaiian		
Strings	Strings: Ens. 1	Violin	Cello	Banjo		
	Strings: Ens. 2	Viola	Mandolin	Harp		
Winds	Trumpet	Trumpet: Muted	Sax: Alto	Flute		
	Trombone	Flugel Horn	Sax: Breathy Tenor	Clarinet		
Organs	Sweet	Mellow	Jazz 1	Pipe		
	Rich	Full	Jazz 2	8'		

	Accordion	Brass Section	Oboe	Sax: Baritone		
More						
	Animal: Cat	Choir	Organ Perc: 2-2/3'	Sax: New Years		
	Animal: Dog	Clavinette	Organ Perc: 4'	Strgs: Pizzicato		
	Bag Pipe	Ens: Big Band	Organ-Combo: 60's	Vibes		
	Bassoon	Fiddle	Organ-Combo: Rock	Vocal: Doo		
	Bells	French Horn	Pan Flute	Whistle		
	Bells: Church	Harmonica: Blues	Piano-El: Detune 1	Xylophone		
	Bells: Crystal	Marimba	Piano-El: Detune 2	Xtra: Solo-Saw		
<b>Dual Sounds</b>	Combine any two Orchestral Sounds + Add any Organ Sound to Dual Sounds.					
Orch. Octave	Move the pitch of Upper/	Move the pitch of Upper/Orchestral Sounds up or down, 1 or 2 octaves.				
Vibra Trem	Add motion and texture to Organ Sounds					
Sustain	Sustain causes Upper Organ sounds to linger and fade away after key release.					
	Left Sounds					
Organs	Organ 8	Organ 4	Organ 8 + 4			
	Accordion	Guitar: Acoustic	Harpsichord	Piano-El: Detune 2		
N.	Bass: Acoustic	Guitar: Nylon	Organ: Pipe	Piano-El: Wurly		
	Bass: Electric	Guitar: Jazz 2	Organ-Combo: 60's	Sax: New Years		
	Bass: Finger Slap	Guitar: Country	Pan Flute	Strings: Ens. 1		
More	Brass Section	Guitar: El. Clean	Piano: Grand	Strings: Ens. 2		
	Choir	Guitar: Rock	Piano: HonkyTonk	Vibes		
	Ens: Big Band	Guitar: Muted	Piano-El: Classic	Vocal: Doo		
	French Horn	Harp	Piano-El: Detune 1	Xtra: Solo-Saw		
Volume Control	Master, Bass, Accompaniment, Drums, Expression Pedal					
Headphones	1/4 Stereo Headphone Jack					
Foot Switch	Glide, Sustain					
LCD Display	Shows a variety of data: Tempo, Chord, Songs, Music Style, Sounds, Values, and Features.					
Feature	Keyboard Split, Touch, Left Sound Vol., Style Vol., Drums Only, Keyed Bass, Reverb, Transpose.					
Keyboard	61 Note-Full Size					
Cabinet	Simulated Rosewood, Matching Bench & Music Rack.					
Bench Pack	Lowrey Songbook with 50 Easy Play Notation Songs, Owner's Guide, AC Power Adapter.					
Dimensions	(Uncrated) 37.75" Wide x 14.50" Deep x 33.00" High-Music Rack removed, 40.00" High-Rack Installed. Weight: 75.50 lbs (with bench)					